

FROG V3




QUICK START GUIDE



OPERATION

POWER BUTTON



- LONG PRESS - ON/OFF
- STANDARD PRESS - CYCLES THROUGH ALL 9 MODES
- QUICK PRESS (WHEN SWITCHED OFF) - BATTERY STATUS

MOUNTING



PLACE THE FROG ON YOUR HANDLEBAR, SEATPOST OR ANY TUBULAR STRUCTURE ON YOUR BIKE (UP TO A MAX OF 32MM DIAMETER) STRETCH THE STRAPS AROUND THE TUBE AND LATCH ON TO THE HOOK

BATTERY STATUS



A QUICK PRESS OF THE POWER BUTTON WHEN THE FROG IS SWITCHED OFF WILL INDICATE THE BATTERY STATUS USING THE LED ARRAY




WHEN THE BATTERY IS RUNNING LOW, THE STRAP HOOK WILL GLOW RED

CHARGING



LIFT CHARGING-PORT HATCH



INSERT USB C CHARGING CABLE



WHEN CHARGING, THE LED ARRAY WILL DISPLAY THE BATTERY STATUS. A FULLY ILLUMINATED ARRAY OF LEDS INDICATES THE FROG IS 100% CHARGED

MODES & RUNTIMES

FRONT

MODE	LUMENS	RUNTIME
High	18	4hr
Low	2	20hr
Side Flash	27	5hr
Full Bright	40	10hr
Back to Front	12	18hr
Front to Back	17	8hr
Side to Side	17	7hr
Rotation	17	18hr
Eco	10	80hr

REAR

MODE	LUMENS	RUNTIME
High	7	3hr
Low	1	15hr
Side Flash	11	4hr
Full Bright	20	7hr
Back to Front	5	13hr
Front to Back	8	6hr
Side to Side	6	5hr
Rotation	6	13hr
Eco	4	60hr

DESIGNED BY KNOG MELBOURNE, AUSTRALIA

2 YEAR WARRANTY

KNOG.COM