




QUICKSTART GUIDE

Knog Plus Free

CHARGE BEFORE FIRST USE



To charge the Plus, remove the mount. Then charge in any USB port.

No cable required.

LED glows red when charging.
LED turns off when fully charged.




TECHNOLOGY

Fixed integrated battery

OPERATION

Long press power button to turn light on and off. Short press to cycle between modes.

The LED below the power button stays on for 2 seconds after turning off when the battery is low.



FITMENT

The Plus Free light is a wearable running and outdoor light. Just attach the light to your tshirt, shorts, socks, headband, backpack or tent using the smart integrated clip.

WARRANTY INFORMATION

This light is guaranteed for 2 years against manufacturing defects only.

The battery is guaranteed for 6 months against manufacturing defects only. See the website for more details.

For more information go to

KNOG.COM.AU